


Cat. No. 2S350 Style No. ALL

- Drill, Enlarge, or Modify Mounting Holes
- 1)Increase hole(s) dia. to 5/8 bolt (.641 drill dia.)
- 2)Move location of mounting hole(s)
- 3)If buying blank lug, put custom hole(s) in.


IHI UL/CSA Installation Guide to Drill or Enlarge Mounting Holes: https://lugsdirect.com/PDF%20Documents/IHI-MTG-HOLE-FIELD-MODS-UL&CSA-CERTIFICATIONS.pdf



NOT FOR USE WHERE FAILURE CREATES A HAZARD TO HUMAN HEALTH OR SAFETY. ALL PRODUCTS ARE SUBJECT TO THIS FULL DISCLAIMER: http://www.ihiconnectors.com/disclaimer.html

FOR FURTHER INFORMATION ON THE PROPER USE OF THIS PRODUCT IN SPECIFIC APPLICATIONS SEE http://www.ihiconnectors.com/GuideToFlexFlexibleFineStrandedWireCableMechanicalLugsFAQ.html

http://www.ihiconnectors.com/Technical-Data-Installation.htm



## FLEX WIRE 262 KCMIL-4 AWG

TEEX WITE 202 ROWIE 47770					
THIS DRAWING AND DESIGN ARE THE PROPERTY OF INTERNATIONAL HYDRAULICS, INC., CLEVELAND, OHIO, AND MAY NOT BE DUPLICATED, USED FOR THE BASIS OF DESIGN OR MANUFACTURE WITHOUT THE WITTEN PERMISSION OF INTERNATIONAL HYDRAULICS, INC., CLEVELAND, OHIO.	INTERNATIONAL HYDRAULICS, INC.				
	TITLE: 2S350-53-56				
GENERAL TOLERANCES ±.015 (±0,038)	CONNECTOR				
MATERIAL: 6061-T6 (X1020)	SIZE:		DWG NO.: 2S350-53-56-(SALES)	REV:	
FINISH:TIN PLATE EMS	DATE: 12/3/08		THIS IS A CAD DRAWING, DO NOT MANUALLY REVISE		